

TABLE OF CONTENTS

GENERAL DESCRIPTION	1
UNPACKING AND ASSEMBLY INSTRUCTIONS	1
PREPARATION FOR USE	2
Power Requirements	2
Mast/Turntable Connections	2
GPIB Interconnections.....	3
Rack Mounting.....	3
OPERATION.....	3
Local Mode	3
Setup Menu.....	4
Main Operating Menu	8
Mast Related Parameters and Functions.....	8
Turntable Related Parameters and Functions	9
Mast and Turntable Common Parameters and Functions.....	10
Remote Mode	12
Remote Screen	12
Programming Model 1090 for Remote Operation.....	13
Reduced Instruction Set.....	13
Expanded Instruction Set.....	17
IEEE-488.2 Standard Mandatory Instruction Set	23
Programming the Service Request.....	25
SYSTEM BLOCK DIAGRAM AND SCHEMATICS	30
WARRANTY	40
SHIPPING LIST.....	41

LIST OF FIGURES

Figure 1. Setup menu layout.....	5
Figure 2. Main menu for antenna masts with factory default settings for the parameter values.....	5
Figure 3. Main menu for turntables with factory default settings for the parameter values.....	6
Figure 4. Remote mode display layout	6


NOTICE: This product and related documentation must be reviewed for familiarization with safety markings and instructions before operation.

SAFETY SYMBOL DEFINITIONS



REFER TO MANUAL

When product is marked with this symbol refer to instruction manual for additional information.



HIGH VOLTAGE

Indicates presence of hazardous voltage. Unsafe practice could result in severe personal injury or death.



PROTECTIVE EARTH GROUND (SAFETY GROUND)

Indicates protective earth terminal. You should provide an uninterruptible safety earth ground from the main power source to the product input wiring terminals, power cord, or supplied power cord set.

CAUTION

HAZARD

CAUTION denotes a hazard. Included text gives proper procedures. Failure to follow instructions could result in minor personal injury and/or property damage.

WARNING

HAZARD

WARNING denotes a hazard. Included text gives proper procedures. Failure to follow instructions could result in severe personal injury and/or property damage.

DANGER

HAZARD

DANGER denotes a hazard. Included text gives proper procedures. Failure to follow instructions could result in severe personal injury and/or death.

GENERAL SAFETY CONSIDERATIONS

1.

BEFORE POWER IS APPLIED TO THIS INSTRUMENT, be sure it has been properly grounded through the protective conductor of the AC power cable to a power source provided with protective earth contact. Any interruption of the protective (grounding) conductor, inside or outside the instrument, or disconnection of the protective earth terminal could result in personal injury.

2.

BEFORE POWER IS APPLIED TO THIS INSTRUMENT, be sure its primary power input has been adapted to the voltage of the AC-power source. Failure to set the AC power input to the correct voltage could cause damage to the instrument when power is applied.

3.

BEFORE REMOVING COVER to perform adjustments or service procedures **TURN POWER OFF**. There are voltages at many points in the instrument which could, if contacted, cause personal injury. Only trained service personnel should perform adjustments and/or service procedures upon this instrument. *Capacitors inside this instrument may still be charged even when instrument is disconnected from its power source.*

4.

TO AVOID A SAFETY HAZARD, replace fuses with the same current rating and type (normal blow, time delay, etc.).

INSTRUCTION AND OPERATION MANUAL
FOR THE
EMCO MODEL 1090
POSITIONING CONTROLLER

GENERAL
DESCRIPTION

The Electro-Mechanics Company (EMCO) Model 1090 Positioning Controller is designed for use with EMCO Antenna Positioning Masts and Turntables to accomplish a variety of EMC tests including FCC and VDE compliance testing.

Four control ports located on the rear panel of the controller allow for the connection of up to four masts, turntables or any combination of both type of devices. Identification codes sent to the controller by the connected devices are used to determine the nature of the devices connected, so that the controller may treat each device appropriately (auto-configuring itself to the environment).

The front panel of the controller contains a 240 X 64 dot, backlit, graphic liquid crystal display (LCD) used for the display of device parameters and operational information. Also on the front panel is a numeric keypad which is used for entering or altering device parameters and invoking functions. A multi-purpose control wheel has been provided to aid in stepping through menu items or for the manual positioning of either masts or turntables.

Control of all devices may be accomplished either in the local mode, through direct interaction with the front panel controls, or in remote mode through use of the GPIB (IEEE-488.1/488.2 standard interface bus) port located on the rear panel. In the remote mode of operation, a reduced instruction set mode, emulating EMCO Models 1050 and 1060 positioning controllers has been provided.

UNPACKING AND
ASSEMBLY INSTRUCTIONS

The Model 1090 Positioning Controller is shipped in a container with an instruction manual, power cord, and appropriate packing material to prevent damage. Unpacking consists of removing the manual, the power

prevent damage. Unpacking consists of removing the manual, the power cord, and the Model 1090 from the container.

No assembly is required.

PREPARATION FOR USE

Power Requirements

The Model 1090 accepts any AC power source input within the range of 90-250V, 50-400Hz. No voltage selection is required. For the application of AC power, a three-conductor power cable is shipped with the instrument. Connecting this cable to an appropriate AC power source causes the instrument chassis to be connected to earth ground.

BEFORE SWITCHING ON THIS INSTRUMENT, THE PROTECTIVE EARTH TERMINAL OF THIS INSTRUMENT MUST BE CONNECTED TO THE PROTECTIVE CONDUCTOR OF THE POWER CORD. THE POWER CORD SHALL ONLY BE CONNECTED TO A SOCKET OUTLET PROVIDED WITH A PROTECTIVE EARTH CONTACT. THIS PROTECTIVE ACTION MUST NOT BE DEFEATED THROUGH THE USE OF AN EXTENSION CORD WITHOUT A PROTECTIVE EARTH CONDUCTOR.

Mast/Turntable Connections

Connection to Model 1090 from either a mast or a turntable is accomplished by means of a single multi-conductor cable (included with the mast or turntable). The cable terminates in a circular bayonet-style connector which is identical at each end. The cable is symmetrical in that either end may be connected to the controller. When connecting the control cable to the controller, caution is advised to observe the keying of the connector in order to prevent possible damage to the connector shell. Additionally, it is advised that excessive lengths of cabling (more than six feet) is not recommended to hang freely from the rear panel of the controller as this will place undue mechanical stress on the connectors and the panel.

Masts and turntables may be connected in any sequence to the four Device Interface Ports located on the rear panel of the instrument. If there are to be less than four devices connected to the instrument, it is recommended

(though not required) that devices be connected in numerical order starting with the Device 1 Interface Port.

GPIB

Interconnections

The Model 1090 is compatible with the General Purpose Interface Bus as described in IEEE-488.1/488.2 standard. A "D" connector has been provided on the 1090 rear panel for connection to a GPIB bus. When making this connection, please note that as a practical matter, the stacking of more than three cables on any one connector should be avoided as this places undue mechanical stress on the connector and rear panel of Model 1090. Additionally, the two connector lockscrews should be made finger tight to avoid the connection being loose during operation.

Provisions have been made for the setting of the instrument's talker/listener bus address through the front panel. Instructions on how to perform this operation may be found in the section of this manual entitled "Setup Menu." Instructions for the programming of the instrument's GPIB interface may be found in the section of this manual entitled "Programming Model 1090 for Remote Operation".

Rack

Mounting

The Model 1090 may be ordered with a rack mount option. This option may be either factory or field installed. This option provides capability for installation in a universal E.I.A. 19 inch rack. The instrument requires 5.25" of rack height (three standard rack height units).

OPERATION

Local

Mode

The Model 1090 is a menu driven instrument. In the local operation mode the current menu is presented on the Parameter Display, and contains the operational parameters which may be altered, and functions which may be invoked. A parameter must be selected before it may be altered, and similarly a function must be selected before it may be invoked. The current parameter/function selection is displayed in reverse video (light characters on a dark background). The current selection is changed by utilizing the POSITIONER wheel on the front panel. Rotating the POSITIONER clockwise will sequentially select menu items in a forward

direction, while rotating the wheel in a counter-clockwise direction reverses the order of menu item selection.

Entering new parameter values or invoking functions is accomplished by means of the numeric keypad. If the selected menu item is an operational parameter such as a lower or upper limit, the keypad will be open for numeric entry. As each key is pressed, the corresponding digit will be pushed into the keypad buffer located at the lower right corner of the parameter display. When the contents of the keypad buffer is equal to the desired value, pressing the ENTER key will transfer this value to the selected parameter.

If the selected menu item is a function such as SEEK or UP/STOP, the keypad will serve to invoke the function. The key which will invoke the function (typically the ENTER key) will be illuminated. More information on specific parameters and functions is detailed in following subsections of this manual.

Setup Menu

The setup menu contains parameters that will either directly affect the instrument's user interface, or will globally apply to each of the connected masts and/or turntables. The setup menu is entered and exited by simultaneously pressing the two keys of the keypad labelled "SETUP" (the "1" and "3" keys.) This menu is illustrated in Figure 1. The operation of these parameters is detailed individually below.

Setting the CURSOR RATE. The cursor rate parameter determines the speed with which the cursor will step through the menu items as the POSITIONER is rotated. There are two settings for the CURSOR RATE, SLOW and FAST. To alter the present setting, select this parameter by first positioning the reverse video cursor over it. The setting may now be toggled by pressing the "+/-" key.

Turning the PANEL-LIGHT ON/OFF. The setting of the PANEL-LIGHT parameter determines whether or not the Parameter Display will be backlit. To toggle the state of this parameter, first select the parameter using the POSITIONER, then press the "+/-" key to turn the backlight ON or OFF.

Turning the Audio ALARM ON/OFF. The setting of the ALARM parameter determines whether or not the audio alarm will be active. This alarm is used to signal the operator in the event of illegal data entries or upon a mast/turntable reaching a preset limit. To toggle the state of this parameter, first select the parameter using the POSITIONER, then press the "+/-" key to activate or deactivate the audio ALARM.

CURSOR RATE SLOW PANEL-LIGHT ON ALARM ON	TURNTABLE MODE NON-CONTINUOUS
POLAR OFFSET DEV1=+000 DEV3=+000 DEV2=+000 DEV4=+000	AUTOINCREMENT=+000
	LISTEN ADDRESS=08

Figure 1. Setup menu layout

UPPR LMT= +400	UP/STOP DOWN/STOP MANUAL	TARG=+100
LWR LMT H=+100		SEEK
LWR LMT V=+100		POLAR H
REM	CYC=001 SCAN	<u>DEV1</u> DEV2 DEV3 DEV4
		CUR POS=+100 +000

Figure 2. Main menu for antenna masts with factory default settings for the parameter values.

CW LMT=+359		CW/STOP		REM
CCW LMT=+000		CCW/STOP		MAN
CYC=001	TARG=+000	DEV1	DEV2	DEV3 DEV4
SCAN	SEEK	CUR POS=+000		+000

Figure 3. Main menu for turntables with factory default settings for the parameter values.

DEV1=+100	M1	ADDRESS NOT DETECTED	LOCAL LOCK-OUT OFF
DEV2=+100	LD +100		
DEV3=+000	UL	LISTEN ADDR=08	
DEV4=+000	M2 AD 1	* NO ERROR *	

Figure 4. Remote mode display layout

Setting Values for POLARization OFFSET. The polarization offset parameter is a vertical displacement (in centimeters) which is applied to the CURRENT POSITION whenever antenna polarization is changed on a mast. The first step in setting this parameter is to determine what the required value is. This will vary with antenna and mount. First, place the mast carrier in the horizontally polarized position, and measure the antenna height. Change the polarization to vertical and note the new antenna height. Subtract the height of the vertically polarized antenna from the antenna height while horizontally polarized, and note this value. Return to the setup menu and position the reverse video cursor over the POLAR OFFSET parameter associated with the device under control. Key in the result of the above subtraction (negative values are permitted). The controller will automatically add this value to the current position parameter when the antenna polarization changes from vertical to horizontal. In the same manner, this value is subtracted from the current position parameter when the polarization is changed from horizontal to vertical. Initializing this parameter to its correct value will insure that the controller does not report erroneous current position data due to changes in antenna polarization.

Setting the TURNTABLE MODE. The TURNTABLE MODE parameter defines how the controller will respond when the current position of a turntable reaches and/or exceeds 360 degrees. If this parameter is set to CONTINUOUS, then the controller will ignore the clockwise and counter clockwise limits which are set in the controller and the current position indicator will reset to zero upon reaching 360 degrees, and will similarly be set to 359 degrees as the table's current position passes through 0 in the opposite direction. **Note that when the controller is operating in the continuous mode, it is capable of turning the turntable in either direction indefinitely if the mechanical limits on the turntable motor base are disabled.** If the parameter is set to NON-CONTINUOUS, the controller will stop the turntable when the current position reaches either one of the clockwise or counter-clockwise limits; depending on the direction of movement of the turntable. To set the TURNTABLE MODE, first place the reverse video cursor over the parameter's present value, and utilize the "+/-" key to toggle this value.

Setting the AUTOINCREMENT Value. The AUTOINCREMENT parameter is associated with the SEEK function, and is applied to both masts and turntables. Each time a SEEK operation is completed, the value of the AUTOINCREMENT parameter will be automatically added to the TARGET parameter value. This value may be either positive or negative. To set this parameter, first place the reverse video cursor over the present value, and use the numeric keypad to enter the desired value (no ENTER is required).

Setting the LISTEN ADDRESS. This parameter is actually the

talker/listener address of the instrument when being operated in remote mode through the GPIB. To set the address, first place the cursor over the present value and use the numeric keypad to enter the desired value (no ENTER is required). The power to the controller should be turned off and then back on for any change of the LISTEN ADDRESS to take effect.

It should be noted, that all of the parameters described above are stored in non-volatile RAM. When power to the instrument is cycled, the values that have been entered will be retained, and need not be reset.

Main Operating Menu

There are two unique main operating menu types; one for the mast and one for the turntable. The menu displayed will be dependent upon the type of the device under control. Two sets of parameters, corresponding to the mast and the turntable, for each one of the four device ports are stored in the non-volatile RAM (total of eight parameter set memory banks). Upon initial power up, the 1090 Controller will examine its four device ports for identification of the connected devices on these ports. The controller will, then, display the appropriate main menu for the first sequentially available device on its ports.

NOTE:WHEN IT IS DESIRED TO CONNECT ONE OR MORE NEW DEVICES TO THE AVAILABLE DEVICE PORT(S) OF THE CONTROLLER, THE USER MUST FIRST TURN OFF THE POWER TO THE CONTROLLER AND THEN CONNECT THE DEVICE(S) TO THE PORT(S). THIS ACTION WILL ASSURE THAT THE CONTROLLER NOTICES THE PRESENCE AND TYPE OF THE NEWLY CONNECTED DEVICE(S).

Refer to Figures 2 and 3 for the following discussion of each of the main menu items.

Mast Related Parameters and Functions

Setting the UPPeR LiMiT. The UPPER LIMIT parameter defines a programmable upper limit of travel (in centimeters) which is independent of the mechanical limits set at the motor base. This value may not exceed +600 and may not be set lower than the value of the active lower limit (horizontal or vertical); factory default setting is +400. While the reverse video cursor is positioned over the current setting of the UPPER LIMIT, this parameter may be changed. Key in the new desired value through the numeric keypad, and verify this value is correct as it appears in the keypad buffer area. Press the ENTER key to transfer the new value to the UPPER LIMIT parameter.

Setting the LoWeR LiMiTs. The LOWER LIMIT parameters define programmable lower limits of travel (in centimeters) which are independent of the mechanical limits set at the motor base. The Model 1090 provides two unique LOWER LIMIT values (in centimeters) for use with masts. Separate and independent limits are provided for horizontal and vertical polarizations. The limit in effect will be indicated by an underscore. This feature offers the operator additional insurance against antenna damage in instances where a long element, when vertically polarized, has the potential for collision with the ground. The values of these parameters may not be set lower than +50 and higher than the upper limit parameter value; factory default setting is +100. To set the limits, after positioning the cursor over the limit to be changed, key in the desired value through the numeric keypad and press ENTER.

Invoking the UP/STOP Function. To cause the mast carrier to move in the upward direction, first place the cursor over the UP/STOP function. Press the ENTER key. The mast shall commence motion, and the ENTER key will illuminate to indicate that it is an active key. Pressing the ENTER key a second time will cease motion. Note that the cursor may not be moved once the device has been set in motion. This is a safety feature, designed to assure immediate access to the STOP command.

Invoking the DOWN/STOP Function. The operation of the DOWN/STOP function is similar to the UP/STOP function, except that it will set the mast to a downward motion. Please see the above paragraph for a complete description.

Changing Antenna POLARization. To change the antenna polarization, first place the cursor over the POLAR parameter. The "+/-" key will illuminate to indicate that it is the active key. Pressing the "+/-" key will toggle the polarization between horizontal (H) and vertical (V). Note that as the polarization changes the active lower limit (underscored) will also change. Verify that the new lower limit is correct. Factory default setting is horizontal polarization.

Turntable Related Parameters and Functions

Setting the ClockWise LiMiT. The CLOCKWISE LIMIT parameter defines a programmable clockwise limit of travel (in degrees) which is independent of the mechanical limits set at the motor base. This value may not exceed +359 and may not be set lower than the value of the counter-clockwise limit; factory default setting is +359. While the reverse video cursor is positioned over the current setting of the CLOCKWISE LIMIT, this parameter may be changed. Key in the new desired value through the numeric keypad, and verify this value is correct as it appears in the keypad buffer area. Press the ENTER key to transfer the new value to the

CLOCKWISE LIMIT parameter.

Setting the Counter-Clockwise LiMiT. The COUNTER-CLOCKWISE LIMIT parameter defines a programmable counter-clockwise limit of travel (in degrees) which is independent of the mechanical limits set at the motor base. This value may not be set lower than 0 and may not exceed the value of the clockwise limit; factory default setting is 0. While the reverse video cursor is positioned over the current setting of the COUNTER-CLOCKWISE LIMIT, this parameter may be changed. Key in the new desired value through the numeric keypad, and verify this value is correct as it appears in the keypad buffer area. Press the ENTER key to transfer the new value to the COUNTER-CLOCKWISE LIMIT parameter.

Invoking the CW/STOP Function. To cause the turntable to move in the clockwise direction, first place the cursor over the CW/STOP function. Press the ENTER key. The turntable shall commence motion, and the ENTER key will illuminate to indicate that it is an active key. Pressing the ENTER key a second time will cease motion. Note that the cursor may not be moved once the device has been set in motion. This is a safety feature, designed to assure immediate access to the STOP command.

Invoking the CCW/STOP Function. The operation of the CCW/STOP function is similar to the CW/STOP function, except that it will set the turntable to a counter-clockwise motion. Please see the above paragraph for a complete description.

Mast and Turntable Common Parameters and Functions

Invoking the MANUAL Function. The MANUAL function allows the operator to directly control the movement of the mast/turntable by means of the POSITIONER knob. To invoke the function, first select it by placing the cursor over the word MANUAL (MAN in case of the turntable). Press the ENTER key. A series of three short tones shall sound to announce that the MANUAL function is active. Further motion of the POSITIONER knob will now be directed to the device under control, and not the cursor. If a mast is being controlled, clockwise motion of the knob will correspond to upward motion. If a turntable is being controlled, clockwise motion of the knob will correspond to clockwise motion of the table. While the MANUAL function is active, pressing the ENTER key at any time will cease all motion and cause the MANUAL function to be exited, this will be announced by one short tone.

Selecting Devices to Control. The current device under control is underscored in the device selection parameter area. To select a new device for control, place the cursor over the desired device and press the ENTER key. If the alarm sounds upon pressing the ENTER key, this is an

indication that the device selected is unavailable for control (not connected to the controller or has been connected to the controller after the last controller power-up). After pressing the ENTER key, the PARAMETER DISPLAY will blank briefly, and then return with a main operating menu appropriate for the device selected.

Invoking the SEEK Function. The SEEK function allows the operator to describe a desired TARGET position for the device under control, and then set the device in motion to "seek" that position. Before invoking the SEEK function, initialize the TARGET parameter by keying in the desired target position, placing the cursor over the current TARGET value and pressing the ENTER key. Next, place the cursor over the word "SEEK" and press the ENTER key. The device will commence motion, and stop when either the TARGET position has been reached or the ENTER key is pressed a second time. Once motion commences, the POSITIONER knob will no longer affect the cursor. This is a safety feature to insure the device under control may be stopped quickly if desired. Upon reaching the TARGET position, the alarm shall sound a series of two short tones. Note that if the AUTOINCREMENT parameter (in the setup menu) has a non-zero value, the TARGET position will be incremented by the value of this parameter. See the section on the setup menu for further details on AUTOINCREMENT. The target position may, at no time (including application of the AUTOINCREMENT value), be set to a value outside the two displayed limits of the device's position.

Invoking the SCAN Function. The SCAN function allows the operator to initiate cyclic motion in the device under control. A cycle is defined as movement from the LOWER/COUNTER-CLOCKWISE LIMIT to the UPPER/CLOCKWISE LIMIT and back to the LOWER/COUNTER-CLOCKWISE LIMIT. The number of cycles that the device will perform is controlled by the CYCLES parameter. As each cycle is completed, the displayed value of the CYCLES parameter will be decremented to indicate the number remaining. Before invoking the SCAN function, place the cursor over the CYCLES parameter and key in the desired value and press the ENTER key. Then place the cursor over the word "SCAN". Pressing the ENTER key will now initiate the SCAN. Note that once motion has commenced, pressing the ENTER key at any time will cause the motion to cease. While the device is moving, the POSITIONER knob will not affect the cursor. This is a safety feature to insure that the device under control may be stopped quickly if desired.

Entering the REMote Mode. The Model 1090 provides for two methods of entering the REMOTE (GPIB control) mode. The first method is automatic, the instrument will enter the REMOTE mode immediately upon receiving its talker/listener address over the GPIB bus. The second method is manual, and is accomplished by placing the cursor over the REMOTE function and pressing the ENTER key. After a series of

three short tones, the Parameter Display will blank momentarily, and return with the REMOTE mode screen.

Changing the CURrent POSition. The CURRENT POSITION parameter is saved in non-volatile RAM and hence is properly retained during power cycling of the instrument. However, since any physical movement of a mast/turntable, while the instrument is not energized, will not be reflected in the CURRENT POSITION, it is highly recommended that this parameter be verified at the beginning of each test session. To change this parameter, place the cursor over the old value, key in the desired value through the numeric keypad and press the ENTER key. This parameter may not be set lower than the lower/counter-clockwise limit and higher than the upper/clockwise limit displayed on the main menu of the device under control. Factory default settings are +100 for masts and 0 for turntables.

Remote Mode

Remote Screen

When the instrument is placed in the REMOTE (GPIB control) mode, either manually or automatically, a unique screen is presented to the operator. This screen is illustrated in Figure 4. The following is a discussion of the information presented within that screen.

Current Position Information. On the left side of the display, the current position of all four devices is presented, regardless of how many devices are connected to the 1090 controller. The units for these values are centimeters for masts and degrees for turntables.

Command Queue. An area just left of center is reserved for a command queue. Contained here is a list of the last five commands (plus any arguments) received by the Model 1090 over the GPIB bus. What is displayed is actually the parsed command, additional spaces or illegal characters will not be displayed, and all characters will appear as upper case.

ADDRESS DETECTED Indicator. In the display's upper half, just right of center is an indicator of a detected Talker/Listener address. Normally this area will contain the words "ADDRESS NOT DETECTED" to indicate that the instrument is not currently addressed as either a Talker or a Listener on the GPIB bus. The "NOT" will disappear whenever the instrument is being addressed by the bus.

LOCAL LOCK-OUT Indicator. In the upper right corner of the display is an indicator of the status of Local Lock-out. This indicator shall read

either "LOCAL LOCK-OUT ON" or "LOCAL LOCK-OUT OFF" accordingly. It should be noted that if Local Lock-out is asserted (ON) by the bus controller, then all front panel controls will be rendered inactive, including the RETURN TO LOCAL key (8) on the keypad.

Talk/LISTEN ADDRESS Indicator. On the right half of the display, just below center is an indicator of the currently selected Talker/Listener address. This two digit address is displayed in decimal, and represents the current address of the 1090 controller on the GPIB bus.

Error Reporting. In the lower right corner of the display, an area has been reserved for the reporting of errors occurring during GPIB data and command transfers. See the Appendix at the back of this manual for an explanation of these messages.

Return To Local. If the Local Lock-out is not asserted (OFF), it is possible for the operator to force the instrument back into the local (front panel control) mode of operation. Under these conditions, the LOCAL key (8) on the numeric keypad will be illuminated, indicating it is active. Pressing the key will cause all moving devices to cease motion, the Parameter Display to blank briefly, and then return with the main operating menu, and control of the instrument to transfer to the front panel.

Programming Model 1090 for Remote Operation

Model 1090 controller recognizes a variety of GPIB (remote) commands. These commands are categorized into three sets; reduced, expanded, and IEEE-488.2 standard mandatory sets. The following are the description of the three sets and their commands.

NOTE: All commands described below may be in either lower case, upper case, or a combination of both. It is recommended, although not required, to terminate each command (including its argument, if any) with the delimiter ";". A space is required between a command and any argument that might follow it.

Reduced Instruction Set

This instruction set is identical to that of the EMCO Model 1050/1060 controllers. Additionally, if one mast and one turntable are connected to the 1090, these devices will be caused to reside at sequential addresses on the GPIB bus. The lower of these two addresses is always even, and will be applied to the mast, the higher or odd address will be applied to the turntable. For example, if the Talker/Listener address is set to 09, then 09

turntable. For example, if the Talker/Listener address is set to 09, then 09 will be the high address (because it is odd) and will be applied to the turntable. The lower address will therefore be 08 and will be applied to the mast. The factory default setting for the Talker/Listen address is 08.

If there are more than one of each type of device is connected to the controller, the address for that device type will apply to the device that is connected to the lowest device port number. For example, if there are two masts connected to the device 1 and device 2 ports and two turntables connected to the device 3 and device 4 ports of the controller, the reduced instruction set commands for the mast will apply to the mast on device 1 port and for the turntable will apply to the one on device 3.

NOTE: When the 1090 controller's state of operation changes from the local mode to remote mode, it is placed in the Reduced Instruction Set mode by default.

IT IS IMPORTANT TO NOTE THAT THE CORRECT INTERPRETATION OF CERTAIN COMMANDS SENT TO THE 1090 IS DEPENDENT ON THE SELECTION OF THE APPROPRIATE MODE (REDUCED OR EXPANDED). IT IS THEREFORE RECOMMENDED THAT THE PROGRAMMER INSURES THAT THE CORRECT MODE IS SELECTED BEFORE ALLOWING THE CONTROLLING SOFTWARE TO PROCEED.

"CC" - Counter-clockwise. This command is applied to the turntable, and causes motion to commence in the counter-clockwise direction if the table has not already reached its counter-clockwise limit. No argument is used with this command.

"CL" - Counter-clockwise Limit. This command is applied to the turntable and provides two distinct functions. The first of these functions is to ready the instrument to respond with the current setting of the counter-clockwise limit when queried. Secondly, if this command follows the "LD" command (see below), it will cause the value of the LD argument to be loaded into the counter-clockwise limit register. No argument is used with this command.

"CP" - Current Position. This command applies to both the mast and the turntable and has two distinct functions. The first of these functions is to ready the instrument to respond with the current position of the addressed device when queried. Secondly, if this command follows the "LD" command (see below), it will cause the value of the LD argument to be loaded into the current position register of the addressed device. No argument is used with this command.

"CW" - Clockwise. This command is applied to the turntable and causes

clockwise motion to commence given that the turntable has not already reached its clockwise limit. No argument is used with this command.

"DN" - Down. This command is applied to the mast, and causes motion to commence in the downward direction, given that the mast has not already reached its lower limit. No argument is used with this command.

"LD" - Load. This command is applied to both the mast and the turntable, and is used to input a numerical value to the instrument. If followed by one of the parameter commands (CP, CL, WL, LL, UL), this numerical value will be loaded into the appropriate parameter register. An argument must be used with this command, and the proper syntax is, then, "LD (+/-)XXX (DG/CM)" where the sign and the units are optional, and the numerical value is expressed in decimal. It should also be noted that if a parameter command is to follow, it may be sent as part of the same string, and need not be separated with a carriage return or line feed.

"LL" - Lower Limit. This command applies to the mast and performs two distinct functions. The first function is to ready the instrument to respond with the current setting of the lower limit when queried. Secondly, if this command follows the "LD" command (see above), it will cause the value of the LD argument to be loaded into the lower limit register. No argument is used with this command.

"M2" - Select the Expanded Instruction Set. This command causes the instrument to move into the Expanded Instruction Set mode. Upon the issuance of this command, all subsequent commands will be interpreted according to the definitions found in the section of this manual titled "Expanded Instruction Set". **It is important to note that not only are more commands available in the Expanded Instruction Set mode, but also commands found in the Reduced Instruction Set may adopt new definitions.** See the individual discussions for details.

"PH" - Horizontal Polarization. This command applies to the mast, and will cause the antenna carrier to move (if the antenna is in vertical polarization) to the position for horizontal polarization. Note that this command will have no effect on masts not equipped with the 90 degree polarization option.

"PV" - Vertical Polarization. This command applies to the mast, and will cause the antenna carrier to move (if the antenna is in horizontal polarization) to the position for vertical polarization. Note that this command will have no effect on masts not equipped with the 90 degree polarization option.

"P?" - Query State of Polarization. This command applies to the mast and will ready the instrument to respond with the present state of antenna

polarization when queried. Upon query, the instrument will return a single ASCII character. The character will be a "0" (zero) if the antenna is vertically polarized or a "1" (one) if the antenna is horizontally polarized.

"ST" - Stop. This command applies to both the mast and the turntable and causes immediate cessation of motion in the addressed device. No argument is used with this command.

"UL" - Upper Limit. This command applies to the mast and has two distinct functions. The first of these functions is to ready the instrument to respond with the current setting of the upper limit when queried. Secondly, if this command follows the "LD" command (see above), it will cause the value of the LD argument to be loaded into the upper limit register. No argument is used with this command.

"UP" - Up. This command applies to the mast, and causes motion to commence in the upward direction, given that the mast has not already reached its upper limit. No argument is used with this command.

"WL" - Clockwise Limit. This command applies to the turntable, and has two distinct functions. The first of these functions is to ready the instrument to respond with the current setting of the clockwise limit when queried. Secondly, if this command follows the "LD" command (see above), it will cause the value of the LD argument to be loaded into the clockwise limit register. No argument is used with this command.

What follows is a brief programming example for the HP-87. It is assumed that there is both a mast and turntable connected to the 1090 controller.

```
10  REMOTE 708,709           !place instrument in remote mode
20  !setup all limits and current positions
30  OUTPUT 708;"LD 50 CM;LL"  !set the mast lower limit
40  OUTPUT 708;"LD +600 UL;"  !set the mast upper limit
50  OUTPUT 708;"LD 50 CP;"    !set the mast current position
60  OUTPUT 709;"LD 0 DG;"
70  OUTPUT 709;"CL;"         !set the counter-clockwise limit
80  OUTPUT 709;"LD 180 WL;"   !set the clockwise limit
90  OUTPUT 709;"LD 0 CP;"     !set the table current position
100 !move the antenna carrier to three meters
110 OUTPUT 708;"CP;"         !ready unit to return cur. position
120 OUTPUT 708;"UP;"         !start the mast upward
130 ENTER 708;POS           !query the current position
140 IF POS<300 THEN GOTO 130 !contin. query until 3m is reached
150 OUTPUT 708;"ST;"        !stop the mast
160 OUTPUT 708;"PV;"        !make polarization vertical
170 !move the turntable to 45 degrees
180 OUTPUT 709;"CP;"        !ready unit to return cur. position
190 OUTPUT 709;"CW;"        !start table clockwise
```

200 ENTER 709;POS	!query the current position
210 IF POS<45 THEN GOTO 200	!contin. query until 45 is reached
220 OUTPUT 709;"ST;"	!stop the turntable

Expanded Instruction Set

The Expanded Instruction Set allows the programmer access to all of the new features of the Model 1090. As a result of this, it contains many new instructions and an unavoidable increase in programming complexity. Each of the instructions is discussed here in detail. This section should be read thoroughly as well as the discussion on "Programming the Service Request" before an attempt is made to utilize the 1090 Controller's full range of features under GPIB control. Some of these instructions, as noted below, may also be executed in the Reduced Instruction Set mode.

*"AD" - **Activate Device.** This command causes the activation of one or more devices (masts or turntables.) Commands issued that invoke functions or set parameter values are applied only to devices which are activated. Once a device is activated, it will remain so until deactivated using the "DD", Deactivate Device command (see below). If a command ("UP" for example) is issued, and no devices are currently active, it will be ignored. Additionally, if more than one device is activated, any issued command, such as "UP", will effect all of the active devices. It is important to note that dissimilar devices (masts and turntables) can not be coincidentally activated. Any attempt to do so will result in a device error. An argument is required by this command, the argument may be a device number (1, 2, 3 or 4) or a combination of device numbers (separated by commas). Below is a usage example.

10 REMOTE 708	!place instrument in remote mode
20 OUTPUT 708;"M2;"	!select expanded instruction set
30 OUTPUT 708;"AD 1;"	!activate device number 1
40 OUTPUT 708;"AD 2,3;"	!activate devices 2 and 3
50 OUTPUT 708;"AD 1,2,3,4;"	!activate all four devices

†"AD?" - **Query Active Devices.** This command readies the instrument to respond to query with a numerical value which represents the currently active devices. The value returned is in decimal format, in the range of 0 to 15. To interpret the result, convert this value to binary. Once in binary format, the least significant bit will correspond to device 1, the next to device 2, etc. A binary digit equal to 1 will be indicative of an activated device. Below is a usage example.

10 OUTPUT 708;"AD?;"	!ready instrument to respond
20 ENTER 708;VAL	!retrieve the numerical value
30 DISP VAL	!display the decimal value

†"AI" - **Set Autoincrement.** This command is used to set the value of

the autoincrement parameter. Note that there is only one autoincrement parameter which is applied to all four devices. An argument is required for this command, and must be of decimal form, in the range of -999 to +999.

†"AI?" - **Query the Autoincrement.** This command readies the instrument to respond with the current setting of the autoincrement parameter when queried. No argument is required with this command.

"CC" - **Counter-clockwise.** This command is applied to turntables only. Issuing this command will cause all activated devices to commence counter-clockwise motion, assuming these devices have not already reached their counter-clockwise limits.

"CL" - **Counter-clockwise Limit.** This command is applied to turntables only, and is used to set the value of the counter-clockwise limit. Upon issuing the command, this parameter will be changed for all active devices. This command requires an argument which is of decimal form, in the range of 0 to clockwise limit. Below is a usage example.

```
10 ! device 1 is a turntable
20 OUTPUT 709;"M2;"           !select Expanded Instruction Set
30 OUTPUT 709;"AD 1;"         !activate device 1
40 OUTPUT 709;"CL +250;"      !set counter-clockwise limit to 250
                               !degrees
```

"CL?" - **Query the Counter-clockwise Limit.** This command is applied to turntables only. Issuing this command readies the instrument to respond with the counter-clockwise limit of the specified device when queried. An argument is required, and must be a device number (1, 2, 3, or 4). The value returned will be a signed decimal number. Below is a usage example.

```
10 ! no devices are currently active, this is not a
20 ! requirement of the CL? command. device 1 is a turntable
30 OUTPUT 709;"M2;"           !select Expanded Instruction Set
40 OUTPUT 709;"CL? 1;"        !ready the instrument to respond
40 ENTER 709;LIMIT            !read the current limit setting
50 DISP LIMIT                 !display the decimal value
```

"CP" - **Set the Current Position.** This command may be applied to both masts and turntables, and is used to set the current position. Upon issuing the command, this parameter will be changed for all active devices. This command requires an argument which is of decimal form, in the range of lower/counter-clockwise limit to upper/clockwise limit.

"CP?" - **Query the Current Position.** This command may be used for both masts and turntables. Issuing this command readies the instrument to respond with the current position of the indicated device when queried.

An argument is required, and must be a device number (1, 2, 3, or 4). The value returned will be a signed decimal number.

"CW" - Clockwise. This command may be applied only to turntables. Issuing this command will cause all activated devices to commence clockwise motion if these devices have not already reached their clockwise limits.

"CY" - Set Cycles. This command is used to set the value of the Cycles parameter for all active devices. An argument is required, and must be a decimal value in the range of 1 to 999.

"CY?" - Query Cycles. This command readies the instrument to respond with the current setting of the CYCLES parameter of the specified device when queried. An argument is required, and must be a device number (1, 2, 3, or 4). The value returned will be an unsigned decimal number in the range of 1 to 999.

†"DIM?" - Query Moving Devices. This command may be used to determine which devices are currently in motion. Issuing this command readies the instrument to respond with a decimal value indicative of the moving devices when queried. The value returned is in decimal format, in the range of 0 to 15. To interpret the result, convert this value to binary. Once in binary format, the least significant bit will correspond to device 1, the next to device 2, etc. A binary digit equal to 1 will be indicative of a device in motion.

***"DD" - Deactivate Device.** This command will deactivate a device or devices that are currently active. An argument is required by this command, the argument may be a device number (1, 2, 3 or 4) or a combination of device numbers (separated by commas).

†"DID?" - Device Identification. This command will prepare the instrument to respond with an identification byte when queried. The returned identification byte contains information about the ports which have a device connected to them and the type of the device that is connected to each port. The byte is returned in its decimal representation which may have a value between 0 and 255. In order to interpret the returned value, the decimal value should be converted to its 8-bit binary representation. The first four least significant bits (bits 1 - 4) of the byte correspond to the four device ports of the 1090 Controller; i. e. the least significant bit (bit 1) corresponds to port 1, the next bit (bit 2) to port 2, etc. A binary value "1" in any of these four bits indicates that there is a device connected to the corresponding port. The most significant four bits (bits 5 - 8) correspond to the least significant four bits (bits 1 - 4); i. e. bit 5 corresponds to bit 1, bit 6 to bit 2, etc. A value "1" in any of the bits 5 through 8 means that the corresponding device (represented by the

corresponding bit in the first four bits) is a turntable, where a bit value "0" means that the device is a mast.

"DN" - Down. This command is applied to masts only. Issuing this command will cause all activated devices to commence downward motion, assuming these devices have not already reached their lower limits. No argument is used with this command.

†**"DS?" - Device Status.** This command is used in the determination of a Service Request's origin. Issuing this command readies the instrument to respond with the contents of the Device Status Register when queried. (For a detailed explanation of the Device Status Register and its function, see the discussion on Programming the Service Request later in this manual). The value returned is in decimal format, in the range of 0 to 15. To interpret the result, convert this value to binary. Once in binary format, the least significant bit will correspond to device 1, the next to device 2, etc. A binary digit equal to 1 will be indicative of a device requesting service.

†**"DSE" - Device Status Enable.** This command is used to set the contents of the Device Status Enable Register. (For a detailed explanation of the Device Status Enable Register and its function, see the discussion on Programming the Service Request later in this manual). A decimal argument is required with a value in the range of 0 to 15. To determine this value, start with a binary byte. The least significant bit will correspond to device 1, the next to device 2, etc. If a device is to be enabled, make the corresponding bit a 1, else make it a 0. Convert the completed byte to decimal, this will be the value of the command's argument.

†**"DSE?" - Query the Device Status Enable Register.** This command readies the instrument to return the contents of the Device Status Enable Register when queried. (For a detailed explanation of the Device Status Enable Register and its function, see the discussion on Programming the Service Request later in this manual). The value returned is in decimal format, in the range of 0 to 15. To interpret the result, convert this value to binary. Once in binary format, the least significant bit will correspond to device 1, the next to device 2, etc. A binary digit equal to 1 will be indicative of an enabled device.

"LH" - Set the Horizontal Lower Limit. This command may be applied only to masts. Issuing this command will set the Lower Limit associated with horizontal antenna polarization of all active devices. A decimal argument, in the range of +50 to the upper limit is required.

"LH?" - Query the Horizontal Lower Limit. This command readies the instrument to respond with the present setting of the Horizontal Lower

Limit for the specified device when queried. An argument is required, and must be a device number (1, 2, 3, or 4). The value returned will be a signed decimal number.

"LL" - Set the Lower Limits. This command may be applied only to masts, and will change the current setting of the Lower Limits (both horizontal and vertical) for all active devices. A decimal argument is required, and must be in the range of +50 to the upper limit.

"LV" - Set the Vertical Lower Limit. This command may be applied only to masts. Issuing this command will set the Lower Limit associated with vertical antenna polarization of all active devices. A decimal argument, in the range of +50 to the upper limit is required.

"LV?" - Query the Vertical Lower Limit. This command readies the instrument to respond with the present setting of the Vertical Lower Limit for the specified device when queried. An argument is required, and must be a device number (1, 2, 3, or 4). The value returned will be a signed decimal number.

†"MODE?" - Query the Mode. This command is used to determine which mode (Reduced Instruction Set or Expanded Instruction Set) the instrument is operating in. Issuing this command readies the instrument to respond with a two byte string indicative of the operating mode when queried. The string returned will be "M1" if in the Reduced Instruction Set mode, or "M2" if in the Expanded Instruction Set mode.

"M1" - Select the Reduced Instruction Set. This command causes the instrument to move into the Reduced Instruction Set mode. Upon the issuance of this command, all subsequent commands will be interpreted according to the definitions found in the section of this manual titled "Reduced Instruction Set".

"PH" - Horizontal Polarization. This instruction is applied to masts only and will cause the antenna carriers of all active devices to move (if in vertical polarization) to the position for horizontal polarization. Note that this command will have no effect on masts not equipped with the 90 degree polarization option.

"PV" - Vertical Polarization. This instruction is applied to masts only and will cause the antenna carriers of all active devices to move (if in horizontal polarization) to the position for vertical polarization. Note that this command will have no effect on masts not equipped with the 90 degree polarization option.

"P?" - Query State of Polarization. This command will ready the instrument to respond with the present state of antenna polarization for the

specified device when queried. An argument is required, and must be a device number (1, 2, 3, or 4.) Upon query, the instrument will return a single ASCII character. The character will be a "V" if the antenna is vertically polarized or an "H" if the antenna is horizontally polarized.

†"RTL" - **Return To Local.** This command will change the state of operation of the instrument from remote mode to local mode. Execution of this command will cause all moving devices to cease motion, the Parameter Display to blank briefly, and then return with the main operating menu, and the control of the instrument to transfer to the front panel.

†"SC" - **Scan.** This command may be applied to both masts and turntables. Issuing this command will cause all active devices to commence scanning between their preset lower and upper limits. The number of scans performed will be determined by the value of the CYCLES parameter which must be independently set prior to issuing the "SC" command.

†"SK" - **Seek.** This command may be applied to both masts and turntables. Issuing this command will cause all active devices to commence seeking for their preset TARGET value. The TARGET parameter must be independently set prior to issuing the "SK" command.

"ST" - **Stop.** This command is applied to masts and turntables, and causes the immediate cessation of motion of all active devices.

"TG" - **Set the Target.** This command may be applied to either masts or turntables, and will set the TARGET parameter of all active devices. A decimal argument is required, and must be in the range of the active lower limit (horizontal or vertical) to upper limit.

"TG?" - **Query the Target.** This command may be applied to either masts or turntables. Issuing this command readies the instrument to respond with the present TARGET parameter setting of the specified device when queried. An argument is required, and must be a device number (1, 2, 3, or 4). Upon query, the instrument will return a signed decimal value.

"UL" - **Set Upper Limit.** This command may be applied to masts only, and will alter the setting of the Upper Limit for all active devices. A decimal argument is required, and must be in the range of the active lower limit (horizontal or vertical) to +600.

"UL?" - **Query the Upper Limit.** This command may be applied to masts only. Issuing this command readies the instrument to respond with the present Upper Limit setting of the specified device when queried. An

argument is required, and must be a device number (1, 2, 3, or 4). Upon query, the instrument will return a signed decimal value.

"UP" - Up. This command may be applied to masts only. Issuing this command will cause all activated devices to commence upward motion, assuming these devices have not already reached their upper limits. No argument is used with this command.

"WL" - Set Clockwise Limit. This command is applied to turntables only, and is used to set the value of the clockwise limit. Upon issuing the command, this parameter will be changed for all active devices. This command requires a decimal argument, in the range of the counter-clockwise limit to +359.

"WL?" - Query the Clockwise Limit. This command is applied to turntables only. Issuing this command readies the instrument to respond with the clockwise limit of the specified device when queried. An argument is required, and must be a device number (1, 2, 3, or 4). The value returned will be a signed decimal value.

* In the Reduced Instruction Set mode, this instruction is recognized but will have no effect.

† This instruction is also valid in the Reduced Instruction Set mode.

IEEE-488.2 Standard Mandatory Instruction Set

In order to comply with the IEEE-488.2 standard, the following instruction set has been provided for the user. All of the commands of this instruction set may be used in either the Reduced or the Expanded Instruction Set modes.

"*CLS" - Clear Status. This command will clear all Event Registers summarized in the Status Byte (For a detailed explanation of the Status Byte and the Event Registers, see the discussion on Programming the Service Request).

"*ESE" - Set the Standard Event Status Enable Register. This command allows the programmer to alter the contents of the Standard Event Status Enable Register. (For a detailed description of this register and its function, see the discussion on Programming the Service Request). A decimal argument in the range of 0 to 255 is required. This argument, when expressed in binary form, directly represents the bit values of the Standard Event Status Enable Register.

"*ESE?" - Query the Standard Event Status Enable Register. This

command readies the instrument to respond with the contents of the Standard Event Status Enable Register when queried. (For a detailed explanation of this register and its function, see the discussion on Programming the Service Request). The response will be a signed decimal number in the range of 0 to +255. This value, when expressed in binary form, directly represents the bit values of the Standard Event Status Enable Register.

"*ESR?" - Query the Standard Event Status Register. This command readies the instrument to respond with the contents of the Standard Event Status Register when queried. (For a detailed explanation of this register and its function, see the discussion on Programming the Service Request). The response shall be a signed decimal in the range of 0 to +255. This value, when expressed in binary form, directly represents the bit values of the Standard Event Status Register. Note that upon reading this register, its contents will be cleared.

"*IDN?" - Identify. This command offers the programmer the ability to determine the nature of the device located at a given address on the GPIB bus. Issuing this command readies the instrument to respond with an ASCII character string when queried. The string that is sent ("EMCO,1090,X.X") uniquely identifies the instrument as an EMCO Model 1090. The X.X parameter is a place-holder for the firmware revision level.

"*OPC" - Arm the Operation Complete Flag. Issuing this command will cause the instrument to set the Operation Complete bit of the Standard Event Status Register when all moving devices have stopped. (For a more detailed description of this operation, see the discussion on Programming the Service Request).

"*OPC?" - Query the Operation Complete. Issuing this command will ready the instrument to respond to query with a single character message. If all moving devices have stopped, the message will be "1" (one) else it will be "0" (zero.)

"*RST" - Reset. Issuing this command will initiate an instrument reset. The instrument shall remain in the remote mode, however, all moving devices will be immediately stopped, and the command queue shall be cleared. The state of the Status Register Data Structure will remain unchanged (for a description of the Status Register Data Structure, see the discussion on Programming the Service Request).

"*SRE" - Set the Service Request Enable Register. This command allows the programmer to alter the contents of the Service Request Enable Register. (For a detailed description of this register and its function, see the discussion on Programming the Service Request). A decimal argument

in the range of 0 to 255 is required. This argument, when expressed in binary form, directly represents the bit values of the Service Request Enable Register.

"*SRE?" - Query the Service Request Enable Register. This command readies the instrument to respond with the contents of the Service Request Enable Register when queried. (For a detailed explanation of this register and its function, see the discussion on Programming the Service Request). The response shall be a signed decimal value in the range of 0 to +255. This value, when expressed in binary form, directly represents the bit values of the Service Request Enable Register.

"*STB?" - Query the Status Byte. This command readies the instrument to respond with the contents of the Status Byte when queried. (For a detailed explanation of this register and its function, see the discussion on Programming the Service Request). The response shall be a signed decimal value in the range of 0 to +255. This value, when expressed in binary form, directly represents the bit values of the Status Byte.

"*TST?" - Self Test. This command readies the instrument to respond with a byte indicative of the self test result. Since the 1090 Controller cannot test its internal circuits without destroying the non-volatile parameter values or with absolute certainty of the cause of any failure, the returned message will always be "0" (zero).

"*WAI" - Wait to Continue. Issuing this command will cause the instrument to place execution of the next command on 'hold' while there are devices in motion. Once motion has ceased, the next command will be executed normally. Note that while a command is on 'hold' additional commands will not be accepted. Normal operation will continue (the "*WAI" command will be released) after the command on 'hold' has been executed. **The time-out option of the GPIB bus controller must be disabled before the execution of the "*WAI" command.**

Programming the Service Request

The Service Request is a form of interrupt, used by instruments on the GPIB bus to inform the controller in charge of changes in status or the existence of a problem. Once an instrument initiates a Service Request, the bus controller must serially poll all the instruments on the bus to determine the source of the interrupt. The instruments respond to the serial poll with a Status Byte which indicates whether or not the instrument is the originator of the Service Request. Once the bus controller finds the originator of the interrupt, it may further interrogate the instrument (read the Status Register Data Structure elements) to discern the exact nature of the request for service.

Each instrument incorporates a Status Register Data Structure. Elements of this structure are largely unique to the instrument, however there are several elements which are standard, as defined in the IEEE 488.2 specification. This data structure provides a means to record "events" and selectively determine if a certain type of "event" should initiate a Service Request. What follows is a discussion of this Status Register Data Structure as it exists in the Model 1090, and how the programmer may use it to properly generate Service Requests on the GPIB bus.

When the 1090 Controller is programmed to initiate a service request upon occurrence of a selected condition and once the selected condition occurs and initiates a request for service, the 1090 Controller will wait indefinitely for the GPIB bus controller to conduct a serial poll on the 1090 Controller. Upon the completion of the serial poll by the bus controller, the 1090 Controller will resume normal operation state and will be ready to respond to the bus controller's inquiries about its Status Register Data Structure.

The Status Byte. The contents of this register form the response to a serial poll initiated by the bus controller in charge. Contained within this register are two single bit summary messages, and one Master Summary Status message. Below, the function of each bit is tabulated.

- Bit 0 - Not used (reset to 0.)
- Bit 1 - Not used (reset to 0.)
- Bit 2 - Not used (reset to 0.)
- Bit 3 - Not used (reset to 0.)
- Bit 4 - Message Available (MAV.) This bit will be set to a 1 if there is a message in the instrument output queue. (Since the Model 1090 always has a message waiting in the output queue, this bit is always set to a 1.)
- Bit 5 - Standard Event Status Summary bit (ESB.) This bit will be set to a 1 if any of the enabled events in the Standard Event Status register occur.
- Bit 6 - Master Summary Status (MSS.) This bit will be set to a 1 if any of the enabled bits of the Status Byte are set to 1.
- Bit 7 - Not used (reset to 0.)

Upon receiving a Service Request, the bus controller will serially poll all instruments on the bus. In response to this poll, each instrument will, in turn, send its Status Byte. The bus controller will examine Bit 6 (MSS) of this Status Byte to determine if the associated instrument is requesting service. Conversely, once the MSS bit is set to a 1 within the 1090 Controller, the instrument will issue a Service Request.

The Service Request Enable Register. This register is used in conjunction with the Status Byte Register. If any bit within this register is

set to a 1, the corresponding bit of the Status Byte will be enabled, and hence contribute towards the Master Summary Status bit. For example, if Bit 5 of the Service Request Enable Register contains a 1, and the corresponding bit of the Status Byte (ESB) is caused to equal 1, the Master Summary Status bit will be set to a 1, and a Service Request initiated. If the ESB had been set to a 1 but Bit 5 of the Service Request Enable Register was cleared to a 0, then the MSS would remain cleared to a 0, and no Service Request initiated. **Note that the bit of the Service Request Enable Register corresponding to the MSS (Bit 6) is not used in the calculation of the MSS.**

The contents of this register may be changed using the "*SRE" command, and queried through use of the "*SRE?" command.

The Standard Event Status Register. This register is a standard structure as defined in the IEEE 488.2 specification. The bit definition as implemented in the Model 1090 is tabulated below.

- Bit 0 - Set to 1 if an Operation Complete message is initiated.
- Bit 1 - Not used (reset to 0.)
- Bit 2 - Not used (reset to 0.)
- Bit 3 - Set to 1 if an internal error occurs.
- Bit 4 - Set to 1 if an error results from a command execution.
- Bit 5 - Set to 1 if an erroneous command is received.
- Bit 6 - Not used (reset to 0.)
- Bit 7 - Set to 1 upon the initial power up.

Any enabled bits in this register (see The Standard Event Status Enable Register below) that are set to a 1 will cause the Standard Event Status Bit (ESB) of the Status Byte to also be set to 1. In this way, lower level events such as the detection of an illegal command can be used to initiate Service Requests. In such an instance, the bus controller would read the instrument's Status Byte, detect that the MSS and the ESB bits were set, indicating that service has been requested because of an event which is defined by the Standard Event Status Register. The controller may then query the contents of the Standard Event Status Register, find Bit 5 set and from this determine that an illegal command has been received by the instrument.

The contents of this register may be queried using the "*ESR?" command. It should be noted that this command will cause the register to be cleared after it is read. The only other command that will affect the contents of this register is the "*CLS" command which will reset all it's bits to 0. The only way bits within this register may be set to a 1 is by the detection of an associated "event".

The Standard Event Status Enable Register. Each bit of this register

may be used to enable the corresponding bit of the Standard Event Status Register. In this way, bits within the Standard Event Status Register may be selectively used to calculate the state of the Standard Event Status Bit (ESB) of the Status Byte, and hence initiate a Service Request.

The contents of this register may be altered using the "*ESE" command, and may be queried using the "*ESE?" command.

The Device Status Register. This register contains information regarding the status of the four devices (masts and/or turntables). The least significant four bits each correspond to one of the four devices, bit 0 (least significant) corresponds to Device 1, bit 1 to Device 2, etc. Each of these bits shall have a value of "0" until a device event occurs (a moving device ceases motion) at which time it will be set to "1". These bits are reset to zero upon one of two conditions; 1) the instrument enters the remote mode or, 2) the GPIB bus controller issues the "DS?" command and queries the contents of this register. This register is used in conjunction with the Device Status Enable Register to determine whether or not an Operation Complete message should be initiated (Setting of the Operation Complete Bit of the Standard Event Status Register to 1).

The contents of this register may not be set directly by the programmer, but may be queried using the "DS?" command.

The Device Status Enable Register. The contents of this register determine which of the four devices are to be considered in generating the Operation Complete message. Bit 0 (least significant) corresponds to Device 1, bit 1 to Device 2, etc. A bit value of 0 signifies that the corresponding device will be ignored in the generation of the Operation Complete message, whereas a bit value of 1 signifies that the corresponding device will be considered when determining an Operation Complete condition. It should be noted that an Operation Complete message will not be initiated until all devices specified in the Device Status Enable Register have registered an event (ceased motion.)

The contents of this register may be altered using the "DSE" command, and queried using the "DSE?" command.

The following is a short programming example, included to clarify the operation and interaction of the registers within the Status Register Data Structure. Additionally, a method of handling a Service Request is presented.

```
005 ! Device 3 connected to the 1090 will be indexed prior to
010 ! each measurement. Set up the 1090 to issue a Service
015 ! Request each time Device 3 reaches its target position
020 ! (ceases motion.)
025 !
```



```


025 REMOTE 708                                !place the 1090 in Remote mode
030 ! 1) Enable Device 3 to form the Operation Complete Message.
035 ! 2) Enable the Operation Complete message to form the
040 !   Standard Event Status Bit summary message (ESB) and
045 ! 3) Enable the ESB to form the Master Summary Message
050 !   (MSS) and hence generate a Service Request.
055 !
060 OUTPUT 708;"DSE 4;"                        !enable Device 3 (bit 2=1)
065 OUTPUT 708;"*ESE 1;"                      !enable the Op. Comp. (bit 0=1)
070 OUTPUT 708;"*SRE 32;"                    !enable the ESB (bit 5=1)
075 ! Enable the bus controller to recognize Service Request
080 ! interrupts, and define the interrupt handling subroutine.
085 !
090 !
095 ON INTR 7 GOSUB 500                        !define the interrupt handler
100 ENABLE INTR 7                             !enable SRQ interrupts
105      :
110      :

500 ! Upon receiving an interrupt, 1) poll the 1090 (read the
505 ! Status Byte) to determine if it is requesting service
510 ! 2) read the 1090's Status Register Data Structure to
515 ! determine the nature of the request (reading the struc-
520 ! also serves to clear all the registers.)
525 !
530 SB=SPOLL(708)                             !retrieve the Status Byte and de-
535 IF BIT(SB,6)=1 GOTO 545                   !termine if service is requested
540 RETURN                                     !if not, return to program.
545 !
550 OUTPUT 708;"DS?;"                          !query the Device Status Register
555 ENTER 708;DS
560 OUTPUT 708;"*ESR?;"                       !query the Standard Event Status
565 ENTER 708;ESR                             !Register
570 IF BIT(ESR,0)=1 GOTO 580                 !verify the Op. Comp. bit is set
575 RETURN                                     !in not, return to program.
580 IF BIT(DS,2)=1 GOTO 590                 !verify Device 3 has completed its
585 RETURN                                     !operation, if not return
590 !
595 ! place the user specific measurement routine here...
600 !
605 RETURN


```

**SYSTEM BLOCK
DIAGRAM AND SCHEMATICS**


The following are the 1090 Controller's block diagram and the schematic drawings of all the printed circuit boards.



MODEL 1090 CONTROLLER SYSTEM BLOCK DIAGRAM




Title		MODEL 109B CONTROLLER	
Size		CPU	
Number	46077	Revision	A
Drawn	5/1/5	Checked	5/1/5
FILE: 46077/5		DESIGN: EXL B. FURR	



DE-D7
ROB-RD7

Size	Number	Revision
1	46078	A
2	46078	B
3	46078	C
4	46078	D
5	46078	E
6	46078	F
7	46078	G
8	46078	H
9	46078	I
10	46078	J
11	46078	K
12	46078	L
13	46078	M
14	46078	N
15	46078	O
16	46078	P
17	46078	Q
18	46078	R
19	46078	S
20	46078	T
21	46078	U
22	46078	V
23	46078	W
24	46078	X
25	46078	Y
26	46078	Z
27	46078	AA
28	46078	AB
29	46078	AC
30	46078	AD
31	46078	AE
32	46078	AF
33	46078	AG
34	46078	AH
35	46078	AI
36	46078	AJ
37	46078	AK
38	46078	AL
39	46078	AM
40	46078	AN
41	46078	AO
42	46078	AP
43	46078	AQ
44	46078	AR
45	46078	AS
46	46078	AT
47	46078	AU
48	46078	AV
49	46078	AW
50	46078	AX
51	46078	AY
52	46078	AZ
53	46078	BA
54	46078	BB
55	46078	BC
56	46078	BD
57	46078	BE
58	46078	BF
59	46078	BG
60	46078	BH
61	46078	BI
62	46078	BJ
63	46078	BK
64	46078	BL
65	46078	BM
66	46078	BN
67	46078	BO
68	46078	BP
69	46078	BQ
70	46078	BR
71	46078	BS
72	46078	BT
73	46078	BU
74	46078	BV
75	46078	BW
76	46078	BX
77	46078	BY
78	46078	BZ
79	46078	CA
80	46078	CB
81	46078	CC
82	46078	CD
83	46078	CE
84	46078	CF
85	46078	CG
86	46078	CH
87	46078	CI
88	46078	CJ
89	46078	CK
90	46078	CL
91	46078	CM
92	46078	CN
93	46078	CO
94	46078	CP
95	46078	CQ
96	46078	CR
97	46078	CS
98	46078	CT
99	46078	CU
100	46078	CV
101	46078	CW
102	46078	CX
103	46078	CY
104	46078	CZ
105	46078	DA
106	46078	DB
107	46078	DC
108	46078	DD
109	46078	DE
110	46078	DF
111	46078	DG
112	46078	DH
113	46078	DI
114	46078	DJ
115	46078	DK
116	46078	DL
117	46078	DM
118	46078	DN
119	46078	DO
120	46078	DP
121	46078	DQ
122	46078	DR
123	46078	DS
124	46078	DT
125	46078	DU
126	46078	DV
127	46078	DW
128	46078	DX
129	46078	DY
130	46078	DZ
131	46078	EA
132	46078	EB
133	46078	EC
134	46078	ED
135	46078	EE
136	46078	EF
137	46078	EG
138	46078	EH
139	46078	EI
140	46078	EJ
141	46078	EK
142	46078	EL
143	46078	EM
144	46078	EN
145	46078	EO
146	46078	EP
147	46078	EQ
148	46078	ER
149	46078	ES
150	46078	ET
151	46078	EU
152	46078	EV
153	46078	EW
154	46078	EX
155	46078	EY
156	46078	EZ
157	46078	FA
158	46078	FB
159	46078	FC
160	46078	FD
161	46078	FE
162	46078	FF
163	46078	FG
164	46078	FH
165	46078	FI
166	46078	FJ
167	46078	FK
168	46078	FL
169	46078	FM
170	46078	FN
171	46078	FO
172	46078	FP
173	46078	FQ
174	46078	FR
175	46078	FS
176	46078	FT
177	46078	FU
178	46078	FV
179	46078	FW
180	46078	FX
181	46078	FY
182	46078	FZ
183	46078	GA
184	46078	GB
185	46078	GC
186	46078	GD
187	46078	GE
188	46078	GF
189	46078	GH
190	46078	GI
191	46078	GJ
192	46078	GK
193	46078	GL
194	46078	GM
195	46078	GN
196	46078	GO
197	46078	GP
198	46078	GQ
199	46078	GR
200	46078	GS
201	46078	GT
202	46078	GU
203	46078	GV
204	46078	GW
205	46078	GX
206	46078	GY
207	46078	GZ
208	46078	HA
209	46078	HB
210	46078	HC
211	46078	HD
212	46078	HE
213	46078	HF
214	46078	HG
215	46078	HH
216	46078	HI
217	46078	HJ
218	46078	HK
219	46078	HL
220	46078	HM
221	46078	HN
222	46078	HO
223	46078	HP
224	46078	HQ
225	46078	HR
226	46078	HS
227	46078	HT
228	46078	HU
229	46078	HV
230	46078	HW
231	46078	HX
232	46078	HY
233	46078	HZ
234	46078	IA
235	46078	IB
236	46078	IC
237	46078	ID
238	46078	IE
239	46078	IF
240	46078	IG
241	46078	IH
242	46078	II
243	46078	IJ
244	46078	IK
245	46078	IL
246	46078	IM
247	46078	IN
248	46078	IO
249	46078	IP
250	46078	IQ
251	46078	IR
252	46078	IS
253	46078	IT
254	46078	IU
255	46078	IV
256	46078	IW
257	46078	IX
258	46078	IY
259	46078	IZ
260	46078	JA
261	46078	JB
262	46078	JC
263	46078	JD
264	46078	JE
265	46078	JF
266	46078	JG
267	46078	JH
268	46078	JI
269	46078	JJ
270	46078	JK
271	46078	JL
272	46078	JM
273	46078	JN
274	46078	JO
275	46078	JP
276	46078	JQ
277	46078	JR
278	46078	JS
279	46078	JT
280	46078	JU
281	46078	JV
282	46078	JW
283	46078	JX
284	46078	JY
285	46078	JZ
286	46078	KA
287	46078	KB
288	46078	KC
289	46078	KD
290	46078	KE
291	46078	KF
292	46078	KG
293	46078	KH
294	46078	KI
295	46078	KJ
296	46078	KK
297	46078	KL
298	46078	KM
299	46078	KN
300	46078	KO
301	46078	KP
302	46078	KQ
303	46078	KR
304	46078	KS
305	46078	KT
306	46078	KU
307	46078	KV
308	46078	KW
309	46078	KX
310	46078	KY
311	46078	KZ
312	46078	LA
313	46078	LB
314	46078	LC
315	46078	LD
316	46078	LE
317	46078	LF
318	46078	LG
319	46078	LH
320	46078	LI
321	46078	LJ
322	46078	LK
323	46078	LL
324	46078	LM
325	46078	LN
326	46078	LO
327	46078	LP
328	46078	LQ
329	46078	LR
330	46078	LS
331	46078	LT
332	46078	LU
333	46078	LV
334	46078	LW
335	46078	LX
336	46078	LY
337	46078	LZ
338	46078	MA
339	46078	MB
340	46078	MC
341	46078	MD
342	46078	ME
343	46078	MF
344	46078	MG
345	46078	MH
346	46078	MI
347	46078	MJ
348	46078	MK
349	46078	ML
350	46078	MM
351		

DIGITAL POT INTERFACE



TITLE MODEL 1898 CONTROLLER		Revision
KEYPAD ASSEMBLY		A
Size Number	46088	
DATE 22-78	173	SHEET 1
FILE 46088/1		OF 1
		FORM 8-1
		REV. B
		REV. C
		REV. D
		REV. E
		REV. F

WARRANTY

The Electro-Mechanics Company (EMCO) warrants that our products are free from defects in materials and workmanship for a period of two years from the date of shipment. If you notify us of a defect within the warranty period, we will at our option, either repair or replace those products which prove to be defective. If applicable, we will also recalibrate the product.

There will be no charge for warranty services performed at the location we designate. You must however, prepay inbound shipping costs and any duties or taxes. We will pay outbound shipping costs for a carrier of our choice, exclusive of any duties or taxes. You may request warranty services to be performed at your location, but it is our option to do so. If we determine that warranty services can only be performed at your location, you will not be charged for our travel related costs.

This warranty does not apply to:

1. Normal wear and tear of materials.
2. Consumable items such as fuses, batteries, etc.
3. Products which have been improperly installed, maintained, or used.
4. Products which have been operated outside of specifications.
5. Products which have been modified without authorization.
6. Calibration of products, unless necessitated by defects.

THIS WARRANTY IS EXCLUSIVE. NO OTHER WARRANTY, WRITTEN OR ORAL, IS EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR PARTICULAR PURPOSE.

THE REMEDIES PROVIDED BY THIS WARRANTY ARE YOUR SOLE AND EXCLUSIVE REMEDIES. IN NO EVENT ARE WE LIABLE FOR ANY DAMAGES WHATSOEVER, INCLUDING BUT NOT LIMITED TO, DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER BASED ON CONTRACT, TORT, OR ANY OTHER LEGAL THEORY.

Please contact our sales department for a Return Material Authorization Number before shipping equipment to us.